

# AMBIC®

## EasiFoamer™

### AAF/030 - PRESSURE TEST GAUGE KIT

The enclosed test gauge kit may be used for testing pressures within the EasiFoamer™ installation – either in the LOW PRESSURE liquid or air pressure lines in the locations 1, 2, or 3 shown in the diagram below.

During INITIAL setting up, both the liquid and air pressure should indicate 4-5psi; adjust air pressure for correct foam quality/wetness.

**NOTE:**

USE ONLY FOR SETTING UP/ADJUSTMENT

- × DO NOT LEAVE THE GAUGE FITTED IN THE LIQUID PRESSURE LINE ALL THE TIME.
- × ALWAYS RINSE OUT GAUGE TUBING/CONNECTORS WITH CLEAN WATER AFTER USE WITH LIQUID / CHEMICAL & STORE IN DRY CONDITIONS.

